


Introduction

The thermostat has the following approximate settings


Rotate the wheel handle clockwise and anti-clockwise between the first and the fifth line to select the required room temperature.



Technical Specification

Maximum working pressure:
Maximum pressure differential:
Maximum water temperature:
Maximum ambient temperature:
Temperature adjustment:
10 bar
100°C
50°C
12°C to 30°C

Dimensions



Bentley Gothic TRV