


## Introduction

The thermostat has the following approximate settings

Rotate the wheel handle clockwise and anti-clockwise between the first and the fifth line to select the required room temperature.



## **Technical Specification**

Maximum working pressure:
Maximum pressure differential:
Maximum water temperature:
Maximum ambient temperature:
Temperature adjustment:

## **Dimensions**

